

Operational Instructions

OI - 5.13 | Scaffold Mats & Ramps

Revision:

B

Section:

5.0 - Plot Groundworks Stage 1

Visual Aids



Information

Task Specific Safety Checks & Notes	Operational Checks
● In the first instance, please ensure you have referred to your site-specific Risk Assessments & Method Statements (RAMS) ● Scaffold mats to be included in the Temporary Works Register	● Scaffold margins are to be installed to the perimeter of houses, garages and screen walls (where required) ● Ensure all margins are left at 3 courses of brickwork below DPC ● The margin is to be constructed from 150mm 6F2 and 50mm MOT Type 1 ● Ensure that the ground level is raised to the underside of formation – do not raise the levels with imported aggregates ● It is to be 2m wide (unless specified differently) – from the edge of the abutting wall ● The edges of the margins are to be neat – use a timber board to create a clean edge ● Ensure margins are properly compacted with a whacker plate ● Temporary stone ramps are to be constructed at plot access points – these are to be constructed from MOT Type 1 and have dpm membrane behind to protect brickwork ● Loading bays are to be extensions of the scaffold margin – in locations instructed by the client ● Timber frame to be considered for scaffold matt widths - 2.5m+
QA Checks & Actions	Operational Standard - References
● Form QMF 27 – Oversight Handover ● Photograph the completed area and include in your photographic daily diary	● N/A