

Operational Instructions

OI - 5.7 | Gas Membrane

Revision:

A

Section:

5.0 - Plot Groundworks Stage 1

Visual Aids



Information

Task Specific Safety Checks & Notes	Operational Checks
● In the first instance, please ensure you have referred to your site-specific Risk Assessments & Method Statements (RAMS) ● Working areas are to be segregated in accordance with MIDA Operational Standard - 2.4 - Segregation - General Working Area and/or MIDA Operational Standard - 2.5 - Segregation - Groundworker Only Area	● Have we checked the specification against client requirements? ● Ensure the floor area is prepared in advance of the sub-contractor's work commencing ● Check that all cavity insulation and fire socks have been installed in advance of the works commencing ● Pre-formed corners are to be used in all instances to create solid connections on each corner ● SVP and Service entry positions are to be covered with pre-formed top-hats ● Minimum lap lengths are to be in line with the detailed specification – ensure the membrane is lapped over the cavities – do not cut the membrane
QA Checks & Actions	Operational Standard - References
● Form QMF 27 – Oversight Handover Sheet ● Ensure any sub-contractor works are checked before being signed off ● Obtain a copy of gas membrane certificate from sub-contractor ● Photograph the completed area and include in your photographic daily diary	● MIDA Operational Standard - 2.4 - Segregation - General Working Area ● MIDA Operational Standard - 2.5 - Segregation - Groundworker Only Area