

Operational Standards

OS - 4.1 | Timber Edging

Revision:	A	Section:	4.0 - Infrastructure Stage 2
-----------	---	----------	------------------------------

Visual Aids



Information

Objective	Application
To correctly fasten the joints at the point of connection between the two pieces of timber	- This applies to permanent timber edging details - Usually detailed in POS areas, retaining feature footpaths
Instructions	
- All timber is to be screwed together – do not use nails - Screw a timber strap to the back of the timber edging at the joint location – do not install the straps or pegs inside the footways - The strap is to be lapped by a minimum of 150mm - Screw the timber peg to the back of the timber strap at the joint location – do not offset the peg	