

# Operational Standards

|                                              |   |          |                                |
|----------------------------------------------|---|----------|--------------------------------|
| OS - 5.10   Temporary Block at Aco Locations |   |          |                                |
| Revision:                                    | A | Section: | 5.0 - Plot Groundworks Stage 1 |

## Visual Aids



# Information

| Objective                                                                                                                                                                                                                                                                                                                                                                               | Application                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------|
| <ul style="list-style-type: none"><li>To reduce remedial works at Stage 2</li></ul>                                                                                                                                                                                                                                                                                                     | <ul style="list-style-type: none"><li>All Aco locations</li></ul> |
| Instructions                                                                                                                                                                                                                                                                                                                                                                            |                                                                   |
| <ul style="list-style-type: none"><li>Once the buried drainage is installed to the sump location – do not install the Aco channels at Stage 1</li><li>Instead, install a row of 100mm blocks, laid flat on a sand &amp; cement bed, where the Aco’s will be installed at a later date</li><li>At Stage 2 – remove the blockwork and install the Aco’s prior to wearing course</li></ul> |                                                                   |