

Operational Standards

OS - 5.3 | Pipework and Wall Separation

Revision:

B

Section:

5.0 - Plot Groundworks Stage 1

Visual Aids



Information

Objective	Application
● To allow movement between SVPs (or services) and blockwork ● To create two separate free-form structures	● All SVPs that concrete surround comes in to contact with sub-structure brick or blockwork ● All service ducting that concrete surround comes in to contact with sub-structure brick or blockwork
Instructions	
● Cut and lay DPM or Correx board against the blockwork ● When surrounding the SVP, ensure that the concrete does not come into direct contact with the blockwork	