

Operational Standards

OS - 5.7 | Plumbers Connection at RWPs

Revision:

B

Section:

5.0 - Plot Groundworks Stage 1

Visual Aids



Information

Objective	Application
● To clearly identify the downpipe positions for the plumber ● To reduce defects	● All RWPs
Instructions	
● Set RWP at 75mm below finished ground level (FGL) ● Install a 400mm long, 90mm dia length of plumbers ducting into the reducing cap and leave exposed above the scaffold margin ● Cap the duct off with duct tape to prevent waste ingress	