

Operational Standards

OS - 5.9 | Service Boxouts

Revision:	A	Section:	5.0 - Plot Groundworks Stage 1
-----------	---	----------	--------------------------------

Visual Aids



Information

Objective	Application
- Clearly identify incoming gas and electric positions at meter box locations - To reduce defects and lost time	All incoming service positions located in hard landscaped areas – i.e: driveways or footways
Instructions	
- Using 4x2 loose timber, box out the incoming gas and electric ducts 600mm wide x 1000mm long - Fill the pit with reject sand	