

Operational Standards

OS - 6.1 | Subsoil Preparation

Revision:

B

Section:

6.0 - Plot Groundworks Stage 2

Visual Aids



Information

Objective	Application
● To break up and loosen the sub-soil prior to placement of topsoil ● To create a sub-formation that allows adequate drainage	● All landscaped areas to rear gardens
Instructions	
● Check design for EV charging cable locations before ripping ● Utilise a ripper tooth attachment on an excavator ● “Rip” the subsoil to a depth of 300mm to loosen and remove any large debris ● Ensure the whole garden is “ripped” ● Handpick any debris from the surface prior to placement of topsoil	